

# PROWOOD 1000 STRAP UPDATE:

**IMPORTANT:** Replacement parts have changed. By adding a Velcro® roll-up tab to the backside of each strap, we've eliminated the need for the Velcro tabs on board top and around handles (previously used to hold straps in rescue-ready position). Read all instructions carefully prior to strap removal and replacement.

## TOOLS NEEDED:

- Medium sized flat-blade screwdriver
- Pliers
- Hammer
- Arrow model T50 staple gun (Available at many hardware stores and home centers)

## OLD STRAP REMOVAL (Refer to diagram A)

- Mark the location of existing staple penetrations to avoid reusing them when stapling new straps.
- Carefully insert a flat-blade screwdriver into the looped end and pry the first staple upward with a rocking motion.
- Once staple is loosened, use pliers to remove. Repeat for each staple.

Note: After strap replacement, Velcro tabs on board top and around handles may be removed at owner discretion.

## NEW STRAP INSTALLATION (Refer to diagram B)

- Straps vary in length. Place longest straps at head-end, and shortest at feet-end, as shown.
- With proper side down, slide the looped strap-end through runner slot, allowing 1-1/2" length for stapling.
- Hold strap firmly in place and staple using four (4) 1/2" T50 stainless steel staples (provided) for each strap.
- Lightly tap each staple with hammer to ensure positive connection.

## CARE AND CLEANING

- After each use, rinse the board, straps, and other parts with chlorine-free water and allow to dry.

## STORAGE (Refer to diagram C)

- Fold each strap in approximately 4" segments. The built-in Velcro roll-up tabs will keep the straps from unrolling.
- Position each strap in rescue-ready position by inserting into the handle slots, as shown.

For information about our full line of C.J. Aquatics Original Replacement Parts, visit our website at [www.cjaquatics.com](http://www.cjaquatics.com).

Thank you!



Jim Metteer  
Director of Manufacturing  
C.J. Aquatics

